

QUICK START GUIDE



1. GRABBING THE NECK CLOSE TO THE HEADSTOCK, SLIDE IT INTO NECK SLOT AND CLICK INTO PLACE



2. TWIST BOLT ON THE BACK UNTIL FIRM



3. BRACE GUITAR WITH KNEES AND PUSH THE NECK BACK AS YOU TIGHTEN THE REST OF THE WAY



4. TUNE UP AND HAVE FUN PLAYING!



To remove the neck, reverse steps 3, 2, 1 - and then press the button.

This guitar has a removable neck, so it works a little differently from a normal guitar. *Scan the QR code for a more detailed guide to get the best playability possible on your collapsible travel guitar!*

Still running into problems? Please reach out to us via email at info@journeyinstruments.com, or contact us at journeyinstruments.com/contact/ for quick support.

